



How To Series

How to Use Grain Filler

Description:	Thixotropic grain filler based on oil based resins, extenders and suitably coloured.
Uses:	To choke or fill the grain before polishing or lacquering to achieve a "full finish"
Colour range:	Transparent (neutral) , Light oak, Dark (brown) Mahogany , Black.
Drying Time:	The grain filler should preferably be left overnight to dry or a minimum of 4 hours.
Method:	Apply with coarse cloth i.e. Curtaining or Hessian in a circular motion, finishing off across the grain. Leave until the 'wet look' has gone then wipe off across the grain with a clean coarse cloth to remove the excess. Leave to dry overnight and paper with 150-180 grit sandpaper.
Finishing:	It will except most stains and can be finished with most types of lacquers and polishes.